

ALTERNATOR NOISE SUPPRESSOR INSTALLATION INSTRUCTIONS

1. Suppression device may be mounted to an existing inner body panel, inner fender bolt (preferably "hidden").
2. Wiring can be run with existing wire loom, and retaped for "hidden" effect.
3. Attach red lead to positive terminal on alternator.
4. Attach black lead to negative terminal on alternator or ground.

